

## Fitting Guide - Hazard Treads

1. Ensure surface on which Anti-Slip Hazard Treads will be applied is clean, dry and free from loose or peeling materials.
2. Apply a thin coat of Anti Slip Floor Primer to the area where Anti-Slip Hazard Treads will be placed and allow to dry fully.
3. Space individual pieces a minimum of ½” and a maximum of 2” apart. Position ½” from stair edges
4. Round the corners of any pieces cut from rolls.
5. Peel protective liner back about 2” from one end and position piece on surface.  
IMPORTANT: Minimize touching adhesive with fingers.
6. Continue to remove liner while firmly pressing exposed Anti-Slip Hazard Treads into place.
7. Press into firm contact with surface using a rubber hand roller by starting in the middle and rolling out to edges.
8. Use Floor Tape Edge Sealer to ensure greater adhesion and longer product life.